HML350PR0精灵3收放起落架升级版安装明书

HML350PRO Auto-retractable landing gear for Phantom series Manual










电子罗盘安装座 Compass mount 3

1

2



按以上方法将收放起落架成品与精灵3机身和脚架连接好,注意指南针模块 安装方向务必和图示一致,否则会导致无法校准或者不能正常飞行

Please install the servos and folding parts to Phantom according to the digram connection . Please pay attention the install direction of the Compass module

4



给起落架通电,通电后如图所示为正常工作状态可以飞行了,如起落架朝反方向运动请断电后互换控制器上1号和2号舵机的插头

Connected to the power(DC7.4V-25.2V), and if the landing gear go back to default position, it mean's successful installation. If not, please exchange the PWM1 and PWM2 plug on the controller

警告和免责声明:

请严格遵守本手册安装和使用该产品。鉴于我们无法控制用户的具体使用、安装、总装、改装以及使用不当等情况,由以上所造成的损害或损伤, 我们将不承担相应的损失及赔偿责任。如果使用、安装、组装该产品,相应的结果由用户承担。因使用本产品而造成的直接或间接损失与伤害, 我们概不负责。

Disclaimer & Warning:

Please strictly follow the manual to assemble and use the retractable landing gear. As We have no controlover use, setup, final assembly, modification or misuse, no liability shall be assumed nor accepted for anyresulting damage or injury. By the act of use, setup or assembly, the user accepts all resulting liability. We

accepts no liability for damage(s) or injuries incurred directly or indirectly from the use of this product.